

The RCA logo is positioned in the top right corner of the page. It consists of the letters 'RCA' in a bold, white, sans-serif font. The background of the entire page is a solid orange color. On the left side, there are two vertical white stripes and a large white circle in the lower right quadrant. There are also three circular punch holes along the left edge of the page.

RCA

**RCA
Universal Arms and
Portable TV
Replacement Antennas**

RCA Universal Arms and Portable TV Replacement Antennas


Index

Page 1	Universal Antenna Arms
Page 2	RCA Replacement Antenna Photos
Page 7	RCA Set Model No. to RCA Replacement Antenna Stock No.
Page 11	RCA Replacement Antenna Stock No. to RCA Set Model No.
Inside Back Cover	Cross Reference for Type and Use with other TV Set Manufacturers

Blister Packed Replacement Antennas

The nine Universal Arms on the opposite page are available in attractively designed boxes or blister packs, similar to the one shown at right. When ordering quantities of these nine antennas, use the 10EB stock numbers if you prefer box packaging (12 per box), and use the 10E stock numbers if you prefer blister packs (1 per card). All other Replacement Antennas shown in this catalog are available in boxes only (1 per box).

RCA Replacement Antenna



10E400

Transceivers,
Walkie-Talkies,
AM-FM Radios

9 Sections Rod

First Section: 23/64" diameter
Extends to 45 1/2"


Easy to Install

Highest quality
chrome plating

Adapter Kit to
Fit Many Imported
and Domestic Models

Parts and Accessories

Trademark(s) Registered
Marcas(s) Registradas(s)
Made in Japan



Universal Antenna Arms

10E100

Universal
Replacement Antenna
for Portable TV

4 Sections Rod

Extends to 38½"
10¾" collapsed.

Fits most portable TV sets.

Easy to Install.
Fastens securely.

Designed for standard
ball-type swivel antenna
mounts.



10E101

Universal
Replacement Antenna
for Portable TV

5 Sections Rod

Extends to 38½"
8¾" collapsed.

Fits most portable TV sets.

Easy to Install.
Fastens securely.

Designed for standard
ball-type swivel antenna
mounts.



10E200

Universal
Replacement Antenna
for Portable TV

5 Sections Rod

Extends to 27¾"
collapsed 6⅞".

Fits most small portable
TV sets.

Easy to Install.
Fastens securely.

Designed for standard
ball-type swivel antenna
mounts.



10E201

Universal
Replacement Antenna
for Portable TV

6 Sections Rod

Extends to 40¾"
collapsed 8¼".

Fits portable TV sets with
large diameter rod.

Easy to Install.
Fastens securely.

Designed for standard
ball-type swivel antenna
mounts.



10E300

Replacement Antenna
for AM-FM Radio and
Micro TV

6 Sections Rod

Extends to 38"
8⅞" collapsed.

Complete with swivel
mount.

Easy to Install.
Highest quality chrome
plated.



10E301

Replacement Antenna
for Sony & Panasonic

8 Sections Rod

Extends to 44¾"
8⅞" collapsed.

Complete with swivel and
hardware.

Easy to Install.
Fastens securely.

Highest quality chrome
plated.



10E400

Transceivers,
Walkie-Talkies,
AM-FM Radios

9 Sections Rod

First Section, ¾" diameter
Extends to 45¾".

Easy to Install.

Highest quality chrome
plating.

Adapter Kit to Fit Many
Imported and Domestic
Models.



10E401

Transceivers,
Walkie-Talkies,
AM-FM Radios

11 Sections Rod

First Section, 1½" diameter
Extends to 54".

Easy to Install.

Highest quality chrome
plating.

Adapter Kit to Fit Many
Imported and Domestic
Models.



10E402

Transceivers,
Walkie-Talkies,
AM-FM Radios

8 Sections Rod


First Section, 1¼" diameter
Extends to 40".

Easy to Install.

Highest quality chrome
plating.

Adapter Kit to Fit Many
Imported and Domestic
Models.






10EB103



10EB107



10EB110




10EB104




10EB108



10EB111



10EB106



10EB109




10EB112



10EB113



10EB116



10EB119



10EB114



10EB117



10EB120



10EB115



10EB118



10EB121
use 10EB120




10EB122



10EB125



10EB128



10EB123



10EB126



10EB129



10EB124



10EB127



10EB130



10EB131



10EB134
use 10EB112



10EB137
use 10EB133



10EB132
use 10EB113



10EB135



10EB138



10EB133



10EB136



10EB139



10EB140

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
AF020J	10EB109	2
AF020J	10EB111	2
AF021 SR	10EB109	2
AF021 SR	10EB111	2
AF045J	10EB108	2
AF045J	10EB109	2
AF049 SR	10EB107	2
AF049 SR	10EB109	2
AF051J	10EB109	2
AF070W	10EB109	2
AF070W	10EB111	2
AF071 SR	10EB109	2
AF071 SR	10EB111	2
AF073 SR	10EB109	2
AF073 SR	10EB111	2
AF085V-VX	10EB108	2
AF085V-VX	10EB109	2
AF090E-H	10EB108	2
AF090E-H	10EB109	2
AF091 SR	10EB108	2
AF091 SR	10EB109	2
AF095 SER	10EB108	2
AF095 SER	10EB109	2
AF097 SR	10EB108	2
AF097 SR	10EB109	2
AF097 SR	10EB109	2
AF100A-B	10EB107	2
AF100A-B	10EB109	2
AF101A-B	10EB107	2
AF101A-B	10EB109	2
AF114 SR	10EB108	2
AF114 SR	10EB109	2
AF115E-W	10EB107	2
AF115E-W	10EB109	2
AF117 SR	10EB107	2
AF117 SR	10EB109	2
AF120W	10EB107	2
AF120W	10EB109	2
AF123W	10EB107	2
AF123W	10EB109	2
AF125 SR	10EB107	2
AF125 SR	10EB109	2
AF141 SR	10EB107	2
AF141 SR	10EB109	2
AF142W	10EB107	2
AF142W	10EB109	2
AF143 SR	10EB107	2
AF143 SR	10EB109	2
AG005J	10EB109	2
AG005J	10EB111	2
AG009 SR	10EB109	2
AG009 SR	10EB111	2
AG013 SR	10EB109	2
AG013 SR	10EB111	2
AG021Y	10EB109	2

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
AG021Y	10EB111	2
AG028J	10EB109	2
AG028J	10EB111	2
AG029 SR	10EB109	2
AG029 SR	10EB111	2
AG030N	10EB109	2
AG030N	10EB111	2
AG050J	10EB109	2
AG050J	10EB111	2
AG055 SR	10EB109	2
AG055 SR	10EB111	2
AG056 SR	10EB109	2
AG056 SR	10EB111	2
AG056 SR	10EB116	3
AG057 SR	10EB109	2
AG057 SR	10EB111	2
AG057 SR	10EB116	3
AG058 SR	10EB109	2
AG058 SR	10EB111	2
AG058 SR	10EB116	3
AG065 SR	10EB109	2
AG065 SR	10EB111	2
AG065 SR	10EB116	3
AG077 SR	10EB109	2
AG077 SR	10EB112	2
AG083 SR	10EB109	2
AG083 SR	10EB112	2
AG089 SR	10EB109	2
AG089 SR	10EB112	2
AG094WRK	10EB109	2
AG094WRK	10EB112	2
AG095 SR	10EB109	2
AG095 SR	10EB112	2
AG118 SR	10EB107	2
AG118 SR	10EB109	2
AG127B-E	10EB107	2
AG127B-E	10EB109	2
AG133 SR	10EB107	2
AG133 SR	10EB109	2
AG135 SR	10EB107	2
AG135 SR	10EB109	2
AG139WK	10EB107	2
AG139WK	10EB109	2
AG143 SR	10EB107	2
AG143 SR	10EB109	2
AG145 SR	10EB107	2
AG145 SR	10EB109	2
AG146WK	10EB107	2
AG146WK	10EB109	2
AG151WK	10EB107	2
AG151WK	10EB109	2
AG155 SR	10EB107	2
AG155 SR	10EB109	2
AG159B-E	10EB107	2
AG159B-E	10EB109	2

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
AG167 SR	10EB107	2
AG167 SR	10EB109	2
AG185J	10EB109	2
AG185J	10EB118	3
AG187 SR	10EB109	2
AG187 SR	10EB117	3
AG187 SR	10EB118	3
AG189 SR	10EB109	2
AG189 SR	10EB117	3
AG189 SR	10EB118	3
AG18J	10EB117	3
AH012 SR	10EB109	2
AH012 SR	10EB120	3
AH027 SR	10EB109	2
AH027 SR	10EB111	2
AH032 SR	10EB109	2
AH032 SR	10EB111	2
AH044Y	10EB109	2
AH044Y	10EB111	2
AH052 SR	10EB109	2
AH052 SR	10EB111	2
AH054 SR	10EB109	2
AH054 SR	10EB111	2
AH063 SR	10EB109	2
AH063 SR	10EB111	2
AH063 SR	10EB116	3
AH066Y	10EB109	2
AH066Y	10EB116	3
AH070 SR	10EB109	2
AH070 SR	10EB111	2
AH070 SR	10EB116	3
AH074 SR	10EB109	2
AH074 SR	10EB111	2
AH074 SR	10EB116	3
AH078 SR	10EB109	2
AH078 SR	10EB112	2
AH082 SR	10EB109	2
AH082 SR	10EB112	2
AH086 SR	10EB109	2
AH086 SR	10EB112	2
AH090 SR	10EB109	2
AH090 SR	10EB112	2
AH126 SR	10EB109	2
AH126 SR	10EB116	3
AH130 SR	10EB109	2
AH130 SR	10EB111	2
AH134 SR	10EB109	2
AH134 SR	10EB111	2
AH134 SR	10EB116	3
AH138WRK	10EB109	2
AH138WRK	10EB111	2
AH138WRK	10EB116	3
AH142 SR	10EB109	2
AH142 SR	10EB111	2
AH142 SR	10EB116	3

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
AH148 SR	10EB109	2
AH148 SR	10EB111	2
AH148 SR	10EB116	3
AH152W	10EB109	2
AH152W	10EB111	2
AH184 SR	10EB109	2
AH184 SR	10EB117	3
AH184 SR	10EB118	3
AH186 SR	10EB109	2
AH186 SR	10EB117	3
AH186 SR	10EB118	2
AH188WK	10EB109	2
AH188WK	10EB117	3
AH188WK	10EB118	3
AH192 SR	10EB109	2
AH192 SR	10EB117	3
AH192 SR	10EB118	3
AH196 SR	10EB109	2
AH196 SR	10EB117	3
AH196 SR	10EB118	3
AJ025E	10EB123	4
AJ025M	10EB123	4
AJ025W	10EB123	4
AJ053J	10EB109	2
AJ053J	10EB124	4
AJ082Y	10EB109	2
AJ082Y	10EB112	2
AM100L	10EB127	4
AM101S	10EB127	4
AP094W	10EB126	4
AP108	10EB131	5
AP121M	10EB125	4
AP151W	10EB125	4
AP159WK	10EB125	4
AP194W	10EB130	4
AP222WEN	10EB129	4
AQ122W	10EB139	5
AQ127T	10EB139	5
AQ200W	10EB140	6
AZ126W	10EB138	5
BG248 SR	10EB113	3
BG248 SR	10EB114	3
BG261 SR	10EB113	3
BG261 SR	10EB114	3
BH204 SR	10EB109	2
BH204 SR	10EB116	3
BH208WK	10EB109	2
BH208WK	10EB116	3
CG223 SR	10EB109	2
CG225W	10EB109	2
CG229L	10EB109	2
CG281 SR	10EB109	2
CG282W	10EB109	2
CG286 SR	10EB109	2
CG287 SR	10EB109	2

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
CG293 SR	10EB109	2
CG299W	10EB109	2
CG305L	10EB109	2
CG313W	10EB109	2
CG314L	10EB109	2
CG317 SR	10EB109	2
CG318W	10EB109	2
CG319F	10EB109	2
CG323 SR	10EB109	2
CG329 SR	10EB109	2
CG330 SR	10EB109	2
CG331L	10EB109	2
CG332 SR	10EB109	2
CG335WK	10EB109	2
CG340 SR	10EB109	2
CG343WK	10EB109	2
CG347LK	10EB109	2
CG351W	10EB109	2
CG353 SR	10EB109	2
CG359 SR	10EB109	2
CG365W	10EB109	2
CG371L	10EB109	2
CG377 SR	10EB109	2
CG383S	10EB109	2
CH224WK	10EB109	2
CH228W	10EB109	2
CH232L	10EB109	2
CH252WK	10EB109	2
CH258 SR	10EB109	2
CH264 SR	10EB109	2
CH270 SR	10EB109	2
CH276WK	10EB109	2
CH280W	10EB109	2
CH288W	10EB109	2
CH294L	10EB109	2
CH300 SR	10EB109	2
CH306F	10EB109	2
CH312WK	10EB109	2
CH320LK	10EB109	2
CH324W	10EB109	2
CH348W	10EB109	2
CH354L	10EB109	2
CH366S	10EB109	2
DG463 SR	10EB109	2
DG465 SR	10EB109	2
DG471W	10EB109	2
DG475L	10EB109	2
EP424W	10EB128	4
EP428WK	10EB128	4
EP506	10EB122	4
EQ327W	10EB133	5
FG525 SR	10EB113	3
FG525 SR	10EB115	3
FH522E	10EB113	3
FH522E	10EB119	3

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
FH526 SR	10EB113	3
FH526 SR	10EB119	3
FH528 SR	10EB113	3
FH528 SR	10EB119	3
FI516B	10EB113	3
FI516B	10EB113	3
FJ549WR	10EB113	3
FQ505W	10EB133	5
FQ505WWR	10EB113	3
FS515W	10EB135	5
FS515W	10EB136	5
GF621 SR	10EB113	3
GF621 SR	10EB114	3
JF163V-W	10EB108	2
JG045W-Y	10EB111	2
JG045W-Y	10EB116	3
K94A112 SR	10EB108	2
K94A112 SR	10EB109	2
K94AX440MV	10EB108	2
K94AX63 SR	10EB108	2
K94AX63 SR	10EB109	2
K94AX70 SR	10EB108	2
K94AX70 SR	10EB109	2
K94AX96 SR	10EB108	2
K94AX96 SR	10EB109	2
K94AX86 SR	10EB109	2
K94B151 SR	10EB109	2
K94B151 SR	10EB110	2
KF185 SR	10EB108	2
KF185 SR	10EB109	2
KF189SR	10EB107	2
KF189SR	10EB109	2
KF191E-W	10EB108	2
KF191E-W	10EB109	2
KF193E-J	10EB107	2
KF193E-J	10EB109	2
KF195W	10EB107	2
KF195W	10EB109	2
140P01	10EB104	2
140P02	10EB104	2
145707	10EB103	2
1457707	10EB103	2
1457707GU	10EB103	2
14PD802	10EB104	2
14PD805	10EB104	2
14PT901	10EB104	2
14PT903	10EB104	2
170P04	10EB106	2
170P042-SR	10EB109	2
170P06	10EB106	2
170PR10	10EB106	2
170T08	10EB106	2
170T12	10EB106	2
170T122-SR	10EB109	2
170TR11	10EB106	2

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
171A03	10EB106	2
171A052-SR	10EB107	2
171A052-SR	10EB109	2
172A042-049	10EB107	2
172A042-049	10EB109	2
172A042-049	10EB109	2
173A472MV-U	10EB107	2
173A472MV-U	10EB109	2
173A502SR	10EB107	2
173A502SR	10EB109	2
17D818	10EB104	2
17PD807E	10EB104	2
17PD809	10EB104	2
17PD809E	10EB104	2
17PT807	10EB104	2
17PT807E	10EB104	2
17PT904	10EB104	2
17PT907	10EB104	2
191A192-SR	10EB107	2
191A192-SR	10EB109	2
191B242-SR	10EB107	2
191B242-SR	10EB109	2
191B242-SR	10EB109	2
191B242-SR	10EB109	2
191B242-SR	10EB109	2
191B242-SR	10EB109	2
191B242-SR	10EB109	2
192A062-SR	10EB109	2
192A072-SR	10EB108	2
192A072-SR	10EB109	2
192A072-SR	10EB109	2
192A072-SR	10EB109	2
192A072-SR	10EB109	2
192A072-SR	10EB109	2
192A094-SR	10EB107	2
192A094-SR	10EB109	2
192A094-SR	10EB109	2
192A094-SR	10EB109	2
192A094-SR	10EB109	2
193A482 SR	10EB108	2
193A482 SR	10EB109	2
193A493MV-U	10EB108	2
193A493MV-U	10EB109	2
193A512 SR	10EB108	2
193A512 SR	10EB109	2
193A522 SR	10EB108	2
193A522 SR	10EB109	2
193A532 SR	10EB108	2
193A532 SR	10EB109	2
193A542 SR	10EB107	2
193A542 SR	10EB109	2
193B570 SR	10EB109	2
193B570 SR	10EB110	2
193K040 SR	10EB108	2
193K040 SR	10EB109	2
21D828	10EB104	2
21D830	10EB104	2
21D860	10EB104	2

RCA Set Model Number	RCA Replacement Antenna Stock No.	Page Number
21PD811	10EB104	2
21PD847	10EB104	2
21PT9095	10EB104	2
21T824	10EB104	2
64A013MV-MU	10EB109	2
64A013MV-MU	10EB111	2
64A026MV-MU	10EB109	2
64A026MV-MU	10EB111	2
64A030 SR	10EB109	2
64A030 SR	10EB111	2
64A052SR	10EB109	2
64A052SR	10EB111	2
6AB14MV	10EB111	2
6AB20SR	10EB109	2
6AB20SR	10EB111	2
94A064MV-MU	10EB108	2
94A064MV-MU	10EB109	2
94A083-4 SR	10EB108	2
94A083-4 SR	10EB109	2
94A102 SR	10EB108	2
94A102 SR	10EB109	2
94A123RS	10EB108	2
94A132 SR	10EB107	2
94A132 SR	10EB109	2
94A144SR	10EB108	2
94A144SR	10EB109	2
94A160 SR	10EB109	2
94A160 SR	10EB110	2
94A171 SR	10EB109	2
94A171 SR	10EB110	2
94A182 SR	10EB109	2
94A182 SR	10EB110	2
94A192 SR	10EB107	2
94A192 SR	10EB109	2
94A203SR	10EB108	2
94A203SR	10EB109	2
94A211 SR	10EB109	2
94A211 SR	10EB110	2
94A233 SR	10EB108	2
94A233 SR	10EB109	2
94A252 SR	10EB109	2
94A252 SR	10EB110	2
9AB32 SR	10EB107	2
9AB32 SR	10EB109	2
9AB41 SR	10EB109	2
9AB41 SR	10EB110	2

RCA
Replacement
Page Stock No. to RCA
No. Set Model No.

2 10EB103
145707
1457707
1457707GU

2 10EB104
140P01
140P02
14PD802
14PD805
14PT901
14PT903
17D818
17PD807E
17PD809
17PD809E
17PT807
17PT807E
17PT904
17PT907
21D828
21D830
21D860
21PD811
21PD847
21PT9095
21T824

2 10EB106
170P04
170P06
170PR10
170T08
170T12
170TR11
171A03

2 10EB107
171A052SR
172A042-049
173A472MV-U
173A502SR
191A192SR
191B242SR
192A094SR
193A542SR
94A132SR
94A192SR
9AB32SR
AF049SR
AF100A-B
AF101A-B
AF115E-W
AF117SR
AF120W
AF123W
AF125SR
AF141SR
AF142W
AF143SR
AG118SR
AG127B-E

RCA
Replacement
Page Stock No. to RCA
No. Set Model No.

2 10EB107 (Cont.)
AG133SR
AG135SR
AG139WK
AG143SR
AG145SR
AG146WK
AG151WK
AG155SR
AG1598-E
AG167SR
KF189SR
KF193E-J
KF195W

2 10EB108
192A072SR
193A482SR
193A493MV-U
193A512SR
193A522SR
193A532SR
193K040SR
94A064MV-MU
94A083-4SR
94A102SR
94A123RS
94A144SR
94A203SR
94A233SR
AF045J
AF085V-VX
AF090E-H
AF091SR
AF095SER
AF097SR
AF114SR
JF163V-W
K94A112SR
K94AX440MV
K94AX63SR
K94AR70SR
K94AX96SR
KF185SR
KF191E-W

2 10EB109
170P042SR
170T122SR
171A052SR
172A042-049
172A042-049
173A472MV-U
173A502SR
191A192SR
191B242SR
191B242SR
191B242SR
191B242SR
191B242SR
191B242SR
192A062SR

RCA
Replacement
Page Stock No. to RCA
No. Set Model No.

2 10EB109 (Cont.)
192A072SR
192A072SR
192A072SR
192A072SR
192A094SR
192A094SR
192A094SR
193A482SR
193A493MV-U
193A512SR
193A522SR
193A532SR
193A542SR
193B570SR
193K040SR
64A013MV-MU
64A026MV-MU
64A030SR
64A052SR
6AB20SR
94A064MV-MU
94A083-4SR
94A102SR
94A132SR
94A144SR
94A160SR
94A171SR
94A182SR
94A192SR
94A203SR
94A211SR
94A233SR
94A252SR
9AB32SR
9AB41SR
AF020J
AF021SR
AF045J
AF049SR
AF051J
AF070W
AF071SR
AF073SR
AF085V-VX
AF090E-H
AF091SR
AF095SER
AF097SR
AF097SR
AF100A-B
AF101A-B
AF114SR
AF115E-W
AF117SR
AF120W
AF123W
AF125SR
AF141SR

RCA
Replacement
Page Stock No. to RCA
No. Set Model No.

2 10EB109 (Cont.)
AF142W
AF143SR
AG005J
AG009SR
AG013SR
AG021Y
AG028J
AG029SR
AG030N
AG050J
AG055SR
AG056SR
AG057SR
AG058SR
AG065SR
AG077SR
AG083SR
AG089SR
AG094WRK
AG095SR
AG118SR
AG127B-E
AG133SR
AG135SR
AG139WK
AG143SR
AG145SR
AG146WK
AG151WK
AG155SR
AG159B-E
AG167SR
AG185J
AG187SR
AG189SR
AH012SR
AH027SR
AH032SR
AH044Y
AH052SR
AH054SR
AH063SR
AH066Y
AH070SR
AH074SR
AH078SR
AH082SR
AH086SR
AH090SR
AH126SR
AH130SR
AH134SR
AH138WRK
AH142SR
AH148SR
AH152W
AH184SR
AH186SR

Page No.	RCA Replacement Stock No. to RCA Set Model No.
2	10EB109 (Cont.)
	AH188WK
	AH192SR
	AH196SR
	AJ053J
	AJ082Y
	BH204SR
	BH208WK
	CG223SR
	CG225W
	CG229L
	CG281SR
	CG282W
	CG286SR
	CG287SR
	CG293SR
	CG299W
	CG305L
	CG313W
	CG314L
	CG317SR
	CG318W
	CG319F
	CG323SR
	CG329SR
	CG330SR
	CG331L
	CG332SR
	CG335WK
	CG340SR
	CG343WK
	CG347LK
	CG351W
	CG353SR
	CG359SR
	CG365W
	CG371L
	CG377SR
	CG383S
	CH224WK
	CH228W
	CH232L
	CH252WK
	CH258SR
	CH264SR
	CH270SR
	CH276WK
	CH280W
	CH288W
	CH294L
	CH300SR
	CH306F
	CH312WK
	CH320LK
	CH324W
	CH348W
	CH354L
	CH366S
	DG463SR

Page No.	RCA Replacement Stock No. to RCA Set Model No.
2	10EB109 (Cont.)
	DG465SR
	DG471W
	DG475L
	K94A112SR
	K94AX63SR
	K94AX70SR
	K94AX96SR
	K94AX96SR
	K94B151SR
	KF185SR
	KF189SR
	KF191E-W
	KF193E-J
	KF195W
2	10EB110
	193B570SR
	94A160SR
	94A171SR
	94A182SR
	94A211SR
	94A252SR
	9AB41SR
	K94B151SR
2	10EB111
	64A013MV-MU
	64A026MV-MU
	64A030SR
	64A052SR
	6AB14MV
	6AB20SR
	AF020J
	AF021SR
	AF070W
	AF071SR
	AF073SR
	AG005J
	AG009SR
	AG013SR
	AG021Y
	AG028J
	AG029SR
	AG030N
	AG050J
	AG055SR
	AG056SR
	AG057SR
	AG058SR
	AG065SR
	AH027SR
	AH032SR
	AH044Y
	AH052SR
	AH054SR
	AH063SR
	AH070SR
	AH074SR
	AH130SR
	AH134SR

Page No.	RCA Replacement Stock No. to RCA Set Model No.
2	10EB111 (Cont.)
	AH138WRK
	AH142SR
	AH148SR
	AH152W
	JG045W-Y
2	10EB112
	AG077SR
	AG083SR
	AG089SR
	AG094WRK
	AG095SR
	AH078SR
	AH082SR
	AH086SR
	AH090SR
	AJ082Y
3	10EB113
	BG248SR
	BG261SR
	FG525SR
	FH522E
	FH526SR
	FH528SR
	F1516B
	F1516B
	FJ549WR
	FQ505WWR
	GF621SR
3	10EB114
	BG248SR
	BG261SR
	GF621SR
3	10EB115
	FG525SR
3	10EB116
	AG056SR
	AG057SR
	AG058SR
	AG065SR
	AH063SR
	AH066Y
	AH070SR
	AH074SR
	AH126SR
	AH134SR
	AH138WRK
	AH142SR
	AH148SR
	BH204SR
	BH208WK
	JG045W-Y
3	10EB117
	AG187SR
	AG189SR
	AG18J
	AH184SR
	AH186SR
	AH188WK

Page No.	RCA Replacement Stock No. to RCA Set Model No.
3	10EB117 (Cont.)
	AH192SR
	AH196SR
3	10EB118
	AG185J
	AG187SR
	AG189SR
	AH184SR
	AH186SR
	AH188WK
	AH192SR
	AH196SR
3	10EB119
	FH522E
	FH526SR
	FH528SR
3	10EB120
	AH012SR
4	10EB122
	EP506
4	10EB123
	AJ025E
	AJ025M
	AJ025W
4	10EB124
	AJ053J
4	10EB125
	AP121M
	AP151W
	AP159WK
4	10EB126
	AP094W
4	10EB127
	AM100L
	AM101S
4	10EB128
	EP424W
	EP428WK
4	10EB129
	AP222WEN
4	10EB130
	AP194W
5	10EB131
	AP108
5	10EB133
	FQ505W
	EQ327W
5	10EB135
	FS515W
5	10EB136
	FS515W
5	10EB138
	AZ126W
5	10EB139
	AQ122W
	AQ127T
6	10EB140
	AQ200W

RCA Portable TV Replacement Antennas

Cross Reference for Type and Use with
other TV Set Manufacturers

RCA St. No.	Drawing No.	JFD	GC	Type	Use
10EB103	972915-7	TA356	61-254	Dipole	
10EB104	973447-2	TA359	32-317	Dipole	Magnavox, Motorola, Packard Bell, Truetone, Traveler, Westinghouse, Philco, Setchell Carlson Ebony
10EB106	962344-6	TA369	61-260	Dipole	
10EB107	1470138-1	TA398	61-262	Monopole	
10EB108	974564-1	TA413	61-248	Monopole	
10EB109	973898-2	TA432	61-266	UHF Loop	Aiwa, Philco, Truetone
10EB110	1440520-1	TA415	61-354	Monopole	Magnavox, Motorola
10EB111	1470138-3	TA461	61-268	Monopole	
10EB112	1470138-5	TA455	61-330	Monopole	GE
10EB113	1472698-1	TA545	—	UHF Bow Tie	Airline, Wells-Gardner, Silvertone
10EB114	1472699-1	TA464	61-176	Monopole	
10EB115	1472673-1	TA393	61-112	Dipole	Dumont, Emerson, Ambassador, Catalina, AMC. Adkins
10EB116	1470138-4	TA466	61-270	Monopole	
10EB117	1470138-6	TA496	61-272	Monopole	
10EB118	1470138-7	TA497	61-274	Monopole	
10EB119	1472977-1	Similar to TA405 Similar to	Similar to 61-412 Similar to	Dipole	Philco, Sylvania
10EB120	1471853-1	TA508	61-838	Monopole	
10EB122	1470138-2	—	—	Monopole	
10EB123	973898-3	TA544	—	UHF Loop	
10EB124	1475258-1	—	—	Monopole	
10EB125	1474735-1	—	—	Monopole	
10EB126	1474832-1	TA527	—	Monopole	
10EB127	1474832-2	TA522	61-716	Monopole	
10EB128	1476430-3	TA526	—	Monopole	
10EB129	1470138-8	—	—	Monopole	
10EB130	1470138-9	—	—	Monopole	
10EB131	1474735-3	—	—	Monopole	
10EB133	1476430-1	—	—	Monopole	
10EB135	1472698-2	TA545	—	UHF Bow Tie	Airline, Wells-Gardner, Silvertone, Ambassador, Bradford Coronada, Motorola, Penncrest, Fleetwood, Packard, Warwick
10EB136	1472699-1	—	—	Monopole	
10EB138	1474832-3	—	—	Monopole	
10EB139	1475258-2	—	—	Monopole	
10EB140	1470138-7	—	—	Monopole	

